

# Bode Analyzer Suite 3.11

## Bugfixes from version 3.00 to 3.11

Bug ID	Description
88863	Blue-screen crash on some PC configurations with Bode 100 R1 devices
88873	Device connection to Bode 100 R1 lost during long, low-RBW measurement
89083	Touchstone file encoding set to UTF-8 to increase file-compatibility
88827	Crash when using cursor jump to zero before a sweep has been completed
92832	Trace math not working when using reverse-sweep measurements
91433	Crash when quickly changing source level during sweep
88864	Delta cursor value not always correct in PDF report and in clipboard image
89000	Crash when opening file with capitalized extension *.BODE3
89017	Crash when using default startup mode and double clicking a .bode3 file
89161	Crash when exporting using variable source-level and no shaped-level points defined
94746	Crash when moving cursor in Nyquist chart using keyboard up-down-right-left

## Known Issues in 3.11

This is a list of known issues in BAS 3.11 that will be resolved in the next version:

Bug ID	Description	Current workaround
95176	Cursor-jump function selection not always working properly during continuous sweeping	Stop sweep to search a maximum or minimum.
95380	Signal Source not always switched off correctly even though icon indicates off	Use single sweep instead of continuous sweep, manually unplug
98075	Calibration not deactivated correctly when changing Rs value in Extended Shunt-Thru with Series Resistor measurement	Take care when changing Rs value
98074	Math values cannot be exported to Touchstone files	Use csv export or copy data to clipboard and manually manipulate Touchstone files