

Bode Analyzer Suite 3.12

Bugfixes from version 3.11 to 3.12

Bug ID	Description
95176	Cursor-jump function selection not always working properly during continuous sweep
95380	Signal Source not always switched off correctly even though icon indicates off
98075	Calibration not deactivated correctly when changing Rs value in Extended Shunt-Thru with Series Resistor measurement
98074	Math values cannot be exported to Touchstone files
95516	Sometimes unhandled exception after closing the application

Known Issues

This is a list of known issues in BAS 3.12 that will be resolved in the next version:

Bug ID	Description	Current workaround
101012	Frequency values in Touchstone export are wrong by factor of 10 when using kHz, MHz or GHz.	Please use Hz
102221	Reference level can't be changed anymore when using Vrms or Vpp display unit in combination with shaped level.	Please use dBm if you need shaped level.