

Bode 100 - Information Note

Loop Gain Measurement

The Voltage Injection Method using the Bode 100 and the B-WIT 100





By Florian Hämmerle © 2017 by OMICRON Lab – V1.1 Visit <u>www.omicron-lab.com</u> for more information. Contact <u>support@omicron-lab.com</u> for technical support.

1 Introduction

Negative feedback is commonly used in control systems in order to control a desired output. The figure below shows the block diagram of a simple system with negative feedback.



The output signal or voltage V(s) follows the reference voltage $V_{ref}(s)$ by the relation

$$G_{CL}(s) = \frac{V(s)}{V_{ref}(s)} = \frac{G(s)}{1 + T(s)}$$

This is generally denoted as the "closed loop transfer function" $G_{CL}(s)$. T(s) is called "loop gain". The loop gain is the product of all gains around the loop which, in this case, equals to T(s) = H(s)G(s).

Knowing the loop gain one can apply the Nyquist stability criterion to assess the overall stability of the closed loop system. The stability assessment is done by e.g. measuring phase margin and gain margin or by checking the Nyquist plot of the loop gain.

The loop gain of a system can be derived from a model of the system. Since models do never consider all parasitics and unwanted effects it is good engineering practice to measure the loop gain of a feedback system in order to validate the system design.



2 Loop Gain Measurement

One practical method to measure the loop gain in electronic feedback systems like DC-DC converters or voltage regulators is the voltage injection method (Middlebrook, 1975). The theoretical derivation of the voltage injection method is shown in the next section. In the following is shown how the voltage injection method can be applied in practice and what has to be considered to achieve correct results.

Using a suitable injection transformer one can inject a test voltage at an appropriate injection-point in the feedback loop. Then the response of the loop can be measured using a vector network analyzer or a frequency response analyzer.

The following figure shows the principle measurement setup to measure the loop gain of a feedback system. A resistor $Z_i(s)$ is inserted in the feedback loop at an appropriate injection-point. The injection resistor size is chosen such that the insertion of the resistor does not change the system. A value of 10Ω is generally suitable for voltage regulators and DC/DC converters. The injection transformer is connected in parallel to the injection resistor in order to apply the test voltage $V_i(s)$ at the injection resistor. This enables the injection of the test voltage without changing the DC operating point of the system.



The analyzers inputs are connected on both sides of the injection resistor using coaxial cables or voltage probes. The loop gain is then measured by measuring the complex voltage gain from point A to B.

$$T_{\nu}(s) = \frac{V_{CH2}(s)}{V_{CH1}(s)}$$

Where T_{v} is the measured loop gain and V_{CH1} and V_{CH2} are the measured voltages at point A (V_{CH2}) and point B (V_{CH1}).



The measured loop gain $T_{\nu}(s)$ approximately equals the "real" loop gain if the impedance looking forward around the feedback loop $Z_{in}(s)$ is much greater than the impedance looking backwards from the injection point $Z_{out}(s)$.

$$V_{ref}(s) V_{e}(s) G(s) V(s) CH 2$$

$$Z_{out}(s) = Z_{i}(s) V_{i}(s) CH 2$$

$$H(s) = CH 1$$

$$H(s) = CH 1$$

The second condition that must be fulfilled to ensure that the measured loop gain approximately equals the real loop gain is:

$$|T(s)| \gg \left| \frac{Z_{out}(s)}{Z_{in}(s)} \right|$$
 Condition 2

It is very important to choose a suitable injection point that fulfills both conditions.

The first condition $|Z_{in}| \gg |Z_{out}|$ is often fulfilled at the output of the voltage regulator which is normally of low impedance characteristic. Further suitable points are generally at high impedance inputs like operational amplifier inputs.

The second condition is more difficult to check. Especially small loop gain results, above the crossover frequency need to be checked very carefully.

The **magnitude** of the injection voltage should be kept low to avoid large signal effects such as saturation or nonlinearities that can influence the measurement result.

The size of the injection resistor does not directly influence the measurement result if it is kept small enough. We recommend using a 10Ω resistor in combination with the B-WIT 100 for best frequency response.

In the following the derivation of the two conditions

 $|Z_{in}(s)| \gg |Z_{out}(s)|$ and $|T(s)| \gg \left|\frac{Z_{out}(s)}{Z_{in}(s)}\right|$ is shown according to (Erickson & Maksimovic, 2001).



 $|Z_{in}(s)| \gg |Z_{out}(s)|$

Condition 1

3 The Voltage Injection Method

In general the loop gain T(s) of a feedback system as shown below can be measured by breaking the feedback loop at a suitable point A where two blocks of the feedback system are connected electrically.



Applying a test voltage $V_x(s)$ after the injection point A leads to the response voltage $V_y(s)$ before the injection point.



The measured loop gain then equals $T_m(s) = \frac{V_y(s)}{V_x(s)}$.

Lets have a closer look at the injection point A where the two blocks B_1 and B_2 are connected electrically and lets extend the model. The output of the first block is modelled with a dependent voltage source G_1V_e including the source impedance Z_{out} . The input of the second block is modelled with an input impedance Z_{in} :





Using the model from above it can be seen that the input impedance of the second block $Z_{in}(s)$ loads the output of the first block. Considering this model which includes the impedances Z_{in} and Z_{out} , the "real" loop gain T(s) of the system can be calculated by:

$$T(s) = G_1(s) \frac{Z_{in}(s)}{Z_{out}(s) + Z_{in}(s)} G_2(s) H(s)$$
(1)

The voltage injection is now included in the model as shown in the following figure



The injecting source is modeled with a voltage source and a series impedance $Z_i(s)$.

In order to measure the loop gain the vector network analyzer is connected to the system and measures

$$T_{v}(s) = \frac{V_{y}(s)}{V_{x}(s)}$$

All other inputs of the system (reference voltage and supply voltage) are considered to be constant showing no AC variations.

According to this model the error voltage is therefore given by

$$V_e(s) = -H(s)G_2(s)V_x(s)$$

Considering the current flowing from block 1 to block 2, the output voltage of block 1 can be written as

$$-V_{y}(s) = G_{1}(s)V_{e}(s) - I(s)Z_{out}(s)$$

Combining these two equations leads to

$$V_{y}(s) = V_{x}(s)G_{1}(s)G_{2}(s)H(s) + I(s)Z_{out}(s)$$
(2)

OMICRO

Smart Measurement Solutions®

The current I(s) can be expressed by

$$I(s) = \frac{V_x(s)}{Z_{in}(s)}$$

Therefore expression (2) becomes

$$V_{y}(s) = V_{x}(s)G_{1}(s)G_{2}(s)H(s) + V_{x}(s)\frac{Z_{out}(s)}{Z_{in}(s)}$$

Hence the measured loop gain equals

$$T_{\nu}(s) = \frac{V_{\nu}(s)}{V_{\chi}(s)} = G_1(s)G_2(s)H(s) + \frac{Z_{out}(s)}{Z_{in}(s)}$$

Expressing the measured loop gain $T_v(s)$ in terms of the acutal loop gain T(s) from (1) leads to

$$T_{v}(s) = T(s) \underbrace{\left(1 + \frac{Z_{out}(s)}{Z_{in}(s)}\right)}_{1^{\text{st term}}} + \underbrace{\frac{Z_{out}(s)}{Z_{in}(s)}}_{2^{\text{nd term}}}$$

The first term of this expression is proportional to the actual loop gain T(s) and is approximately equal to T(s) when

$$|Z_{in}(s)| \gg |Z_{out}(s)|$$

Which is the first condition necessary to fulfill $T_{v}(s) \approx T(s)$.

The second term limits the minimum loop gain that can be measured using the voltage injection method. If this term is much smaller than the loop gain it can be ignored. Thus we arrive at the second condition to ensure $T_v(s) \approx T(s)$:

$$|T(s)| \gg \left| \frac{Z_{out}(s)}{Z_{in}(s)} \right|$$

The injection resistor respectively injection voltage does influence the loading from block 2 on block 1. However, if condition 1 is satisfied and the test signal is kept small comparing to the absolute signal, this effect is negligible.

References

Erickson, R. W., & Maksimovic, D. (2001). *Fundamentals of Power Electronics.* Springer. Middlebrook, R. (1975). Measurement of loop gain in feedback systems. *38*.





OMICRON Lab is a division of OMICRON electronics specialized in providing Smart Measurement Solutions to professionals such as scientists, engineers and teachers engaged in the field of electronics. It simplifies measurement tasks and provides its customers with more time to focus on their real business.

OMICRON Lab was established in 2006 and is meanwhile serving customers in more than 50 countries. Offices in America, Europe, East Asia and an international network of distributors enable a fast and extraordinary customer support.

OMICRON Lab products stand for high quality offered at the best price/value ratio on the market. The products' reliability and ease of use guarantee trouble-free operation. Close customer relationship and more than 30 years in-house experience enable the development of innovative products close to the field.

Europe, Middle East, Africa OMICRON electronics GmbH Phone: +43 59495 Fax: +43 59495 9999 Asia Pacific OMICRON electronics Asia Limited Phone: +852 3767 5500 Fax: +852 3767 5400 Americas OMICRON electronics Corp. USA Phone: +1 713 830-4660 Fax: +1 713 830-4661